


**QUICK START GUIDE**



Bluetooth v5.3

FSTYLER COLLECTION


**WHAT'S IN THE BOX**




**KNOW YOUR PRODUCT**



**CONTROL ON YOUR FINGERS**



**WIDE COMPATIBILITY**



**USB BLUETOOTH ADAPTOR**

To connect the headphone to the non-Bluetooth device, a Bluetooth adaptor is needed. Instantly transform your computer, TV, or other audio source device into a Bluetooth-enabled one with the Bluetooth Adaptor. Just plug and play. No software installation is required.



**CONNECTING BLUETOOTH DEVICE**


(For The First Time Use)



- Long press the power button for 2S, the indicator light flashes in red and blue alternately when pairing.
- Choose "A4TECH BH230" from your Bluetooth device.
- The indicator flashes in Blue slowly after the headset is connected.

**CONNECTING BLUETOOTH DEVICE**


(For The Second Time Use)



**The device you connected last time will be remembered. Automatically connect back to the last device after power on.**

**Warm Tips:** Make sure the Bluetooth devices is turned on.

**CHARGING/LOW BATTERY INDICATOR**



Flashing red light indicates when the battery is below 25%.

**TECH SPEC**

Headset Model No.:	BH230
Adaptor Model No.:	BN-10
Speaker Unit:	40mm
Frequency:	20Hz - 20KHz
Impedance:	32 ohm
Sensitivity:	98 dB
Mic. Type:	ENC Single-Directional
Mic. Frequency:	100Hz - 10KHz
Mic. Sensitivity:	-42 dB
Wireless Mode:	Bluetooth v5.3
Operation Distance:	Up to 10 m (32 feet)
Battery Type:	400mAh Lithium Battery
Charging Time:	1.5H
Playback Time:	55 Hours (50% volume)
USB Type-C Charging Cable:	50 cm
Weight:	156g (Headset Only)

**SAFETY RULES**

- To avoid hearing damage, do not use headphones at a high volume for a long time.
- Never disassemble or modify your headphones for any reason. Otherwise, it may cause the headphones to malfunction, which is not covered by the warranty.
- Do not get the device wet with liquids, otherwise will cause serious damage to the device. Damage caused by water entering the device will not be covered by the manufacturer's warranty.
- Please do not place the product in an environment where the temperature is too high or too low (above 45°C or below -20°C).
- Not suitable for children under 3 years old.
- Do not use the device during a thunderstorm.

**WARNING STATEMENT**

THE FOLLOWING ACTIONS MAY DAMAGE THE PRODUCT.


- To disassemble, bump, crush, or throw into the fire is forbidden for lithium batteries.
- Do not expose under the strong sunlight.
- The discard of the battery should obey the local law, if possible please recycle it. Do not dispose of it as household garbage, because it may cause an explosion.
- Do not continue to use if severe swelling occurs.
- Please try to avoid charging in an environment below 0°C.
- The user is not allowed to remove or replace the batteries unless specified statement in the user manual.



The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by A4TECH is under license. Other trademarks and trade names are those of their respective owners.



www.a4tech.com



Scan for E-Manual