

SAFETY RULES

• When not in use, disconnect the external device from the product first. For example, shut down the external device or "safely eject" the external device from the computer. Then disconnect the product from the computer. $\left(\overline{\mathbf{y}} \right)$

- Do not operate in a humid environment.
- Do not plug or unplug the product too hard in case of damage.
- Keep out of reach of children.