

Windows / Android / Mac / iOS

OTHER EN SHORTCUTS SWITCH

Android

Pause

Device Screen

Device Screen

Screen Lock

Switching Steps:

① Choose iOS layout by pressing Fn+I.
② Choose MAC layout by pressing Fn+O
③ Choose Windows / Android layout by pressing Fn+P.

Brightness +

Brightness -

Mac / iOS

Pause

Device Screen

Brightness +

Brightness -Screen Lock (iOS Only)

Mac / iOS (ios&mac)

Control ^

Option ~

Command 34

Command 38

(os)

Note: The final function refer to the actual system. **DUAL-FUNCTION KEY**

Ctrl

Alt

Start 👭

Alt-Right

Windows / Android (W / A)

Windows

Pause

Device Screen

Device Screen

Brightness +

Brightness -

Shortcuts

delete

Multi-System Layout

I O P

ctrl

alt

alt

cmd ೫

Keyboard Layout

ettl opt ~	Ctrl-Right	Option ~	
LOW BA	TTERY INDIC	CATOR	*
	FRITYLER.	*., *., *., *., * * * * * *	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0


Flashing Red light when the battery is below 10%.

Character: Laser Engraving Includes: Keyboard, Nano Receiver, 1 AA Alkaline Battery, Type-C Adaptor, USB Extension Cable, User Manual System Platform: Windows / Mac / iOS / Chrome / Android / Harmony OS...

SPECIFICATIONS

Connection: Bluetooth / 2.4GHz Multi-Device: Bluetooth x 3, 2.4G x 1

Operation Range: 5-10 m Report Rate: 125 Hz



Answer The device you connected last time will be remembered. Question How can I know the current device is connected or not? Answer When you turn on your device, the device indicator will be solid.

(disconnected: 5S, connected: 10S)

Question Does the keyboard remember the connected device?

Question How to switch between connected Bluetooth device 1-3? Answer By pressing FN + Bluetooth shortcut (7 - 9).

WARNING STATEMENT

1. To disassemble, bump, crush, or throw into fire is forbidden for the battery.

3. The discard of battery should obey to the local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause an explosion. 4. Do not continue to use if severe swelling occurs. 5. Please do not charge the battery.

2. Do not expose under the strong sunlight or high temperature.

The following actions may damage the product.





Scan for E-Manual

STYLER_ COLLECTION



A4TECH