

130\*70mm





# SYSTEM SWAP MAC WIN OWERTYUISE SOFEGHUIKLES

#### WINDOWS/MAC OS KEYBOARD LAYOUT

System	Shortcut [Long Press for 3S]	Indicator Light
Windows		⊜m/w
Mac OS	fn + 💿	Flashing Off

QUIETKØ

Note: Windows is default system layout. The device will remember the last keyboard layout, please switch as needed.

### FN MULTIMEDIA KEY COMBINATION SWITCH

FN Mode: You can lock & unlock Fn mode by short pressing FN + ESC by turn.

Previous Track Play / Pause Next Track Mute

Lock Fn Mode: No need to press FN key
 Unlock Fn Mode: FN + ESC
 \* After pairing, FN shortcut is locked in FN mode by default,

Screen Capture

and the locking FN is memorized when switching and shutting down.

### **DUAL-FUNCTION KEY**

Input

Switching

Multi-System Layout

Backward

Search

System Switching

Home Page

fin

Shortcuts	win (Windows)	mac (Mac OS)
	Switching Steps: ① Choose Mac layout by pressing Fn+O. ② Choose Windows layout by pressing Fn+P.	
cri	Ctrl	Control ^
	Start	Option 🛰
	Alt	Command 🕷
	Alt (Right)	Command 🕷
	Ctrl (Right)	Option ᅮ

### Q & A

(FN)

Volume Up

olume

Down

Question Can the keyboard support Mac platforms?

(Answer) Support: Windows | Mac keyboard layout switching.

#### Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

#### Question Why can't the function lights in Mac system prompt?

(Answer) Because Mac system does not have this function.

## WARNING STATEMENT

The following actions may damage the product.

- 1. To disassemble, bump, crush, or throw into fire is forbidden for the battery.
- 2. Do not expose under the strong sunlight or high temperature.
- The discard of battery should obey to the local law, if possible please recycle it.
  Do not dispose it as household garbage, because it may cause an explosion.
- 4. Do not continue to use if severe swelling occurs.
- 5. Please do not charge the battery.



COLLECTION





www.a4tech.com

Scan for E-Manual

 $\overline{\mathbb{V}}$