




FSTYLER.









FSTYLER LOW PROFILE SCISSOR SWITCH KEYBOARD QUICK START GUIDE

**FX51** 

(www.a4tech.comQ



Low Profile Scissor Switch Keyboard

### (Windows/Mac OS Keyboard Layout)

System	Shortcut [Long Press for 3S]	Indicator Light
Windows	fn + P	<b>⊝</b> m/w
Mac OS	fn + O mac	Flashing Off

Note: Windows is default system layout.

The device will remember the last keyboard layout, please switch as needed.

#### (FN Multimedia Key Combination Switch)

FN Mode: You can lock & unlock Fn mode by short pressing FN + ESC by turn.

① Lock Fn Mode: No need to press FN key 2) Unlock Fn Mode: FN + ESC

\* After pairing, FN shortcut is locked in FN mode by default, and the locking FN is memorized when switching and shutting down.




Track











www.a4tech.com

#### TSTYLER.

Low Profile Scissor Switch Keyboard

#### Other FN Shortcuts Switch

Shortcuts	win (Windows)	mac (Mac OS)
fn + delete	Pause	Pause
fn + 🗘	Brightness +	Brightness +
fn+ v	Brightness -	Brightness -
fn + enter	Scroll Lock	Not Support

Note: The final function refer to the actual system.

## ( Dual-Function Key )

Shortcuts	win (Windows)	mac (Mac OS)
fn + 0 / P	Switching Steps: ① Choose Mac layout by pressing Fn+O. ② Choose Windows layout by pressing Fn+P.	
ctrl	Ctrl	Control ^
Harton Harton	Start 📲	Option ~_
ord III	Alt	Command 3%
olt ord II	Alt (Right)	Command 🦋
ला क्रिक	Ctrl (Right)	Option ~

www.a4tech.com

# (Product Specifications)

Model: FX51

Switch: Scissor Switch

TSTYLER.

Actuation Point: 1.8 ± 0.3 mm

**Keycaps:** Chocolate Style

Character: Silk Printing + UV

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 - F12

Report Rate: 125 Hz

Cable Length: 150 cm

Port: USB

Includes: Keyboard, USB Type-C Cable, User Manual

System Platform: Windows / Mac

www.a4tech.com

Q & A

"FSTYLER.

Low Profile Scissor Switch Keyboard

Question Can the keyboard support Mac platforms?

Answer Support: Windows | Mac keyboard layout switching.

Low Profile Scissor Switch Keyboard

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.

Question Can the mobile phone USB-Type C charging cable be used here?

Answer Only supports 5-core USB Type-C data cables. (Suggest to use the package included cable.)

www.a4tech.com