




www.a4tech.com

Product Features



www.a4tech.com

Package Including



Illuminate Keyboard



User Manual

www.a4tech.com



FSTYLER ILLUMINATE LOW PROFILE SCISSOR SWITCH KEYBOARD QUICK START GUIDE

FX60

www.a4tech.com


Windows/Mac OS Keyboard Layout

System	Shortcut [Short Press for 1S]	Indicator Light
Windows		Scroll Lock
Mac OS		Scroll Lock Flashing Off

Note: Windows is default system layout. The device will remember the last keyboard layout, please switch as needed.

FN Multimedia Key Combination Switch

FN Lock Mode: To select the Multimedia features as your main command, lock the FN mode by pressing FN+ESC. To unlock, press FN+ESC again.



www.a4tech.com

Other FN Shortcuts Switch

Shortcuts	win (Windows)	mac (Mac OS)
+	Keyboard Backlit + / -	Keyboard Backlit + / -
+	Device Brightness + / -	Device Brightness + / -
+	Scroll Lock	Not Support

Note: The final function refer to the actual system.

Dual-Function Key

Shortcuts	win (Windows)	mac (Mac OS)
/	Switching Steps: ① Choose Windows layout by pressing win. ② Choose Mac OS layout by pressing mac.	
^	Ctrl	Control ⌘
⌘	Start	Option ⌥
⌘	Alt	Command ⌘
⌘	Alt (Right)	Command ⌘
⌘	Ctrl (Right)	Option ⌥

www.a4tech.com

Product Specifications

**Model:** FX60

**Switch:** Scissor Switch

**Actuation Point:** 1.8 ± 0.3 mm

**Keycaps:** Chocolate Style

**Character:** Silk Printing + UV

**Keyboard Layout:** Win / Mac

**Hotkeys:** FN + F1 ~ F12

**Report Rate:** 125 Hz

**Backlit Adjustable:** FN +

**Cable Length:** 150 cm

**Port:** USB

**Includes:** Keyboard, User Manual

**System Platform:** Windows / Mac

www.a4tech.com

Q & A

**Question** Can the keyboard support Mac platforms?

**Answer** Support: Windows | Mac keyboard layout switching.

**Question** Does the layout can be remembered?

**Answer** The layout you used last time will be remembered.

**Question** Why does the function light not indicate in Mac OS System?

**Answer** Because the Mac OS system does not have this function.

www.a4tech.com