



FSTYLER ILLUMINATE LOW PROFILE SCISSOR SWITCH KEYBOARD QUICK START GUIDE

FX60H

(www.a4tech.comQ



ILLUMINATE

TSTYLER.

(Windows/Mac OS Keyboard Layout)

System	Shortcut [Short Press for 1S]	Indicator Light
Windows	win	*scroll lock Scroll Lock Flashing Off
Mac OS	mac	


Illuminate Low Profile Scissor Switch Keyboard

Note: Windows is default system layout.

The device will remember the last keyboard layout, please switch as needed.

(FN Multimedia Key Combination Switch)

To unlock, press FN+ESC again.



www.a4tech.com

Illuminate Low Profile Scissor Switch Keyboard

(Other FN Shortcuts Switch)

Shortcuts	win (Windows)	mac (Mac OS)
fn+◀ ▶	Keyboard Backlit + / -	Keyboard Backlit + / -
fn⊹▲▼	Device Brightness + / -	Device Brightness + / -
fn+ enter	Scroll Lock	Not Support

Note: The final function refer to the actual system.

(Dual-Function Key)

Shortcuts	win (Windows)	mac (Mac OS)
mac / win	Switching Steps: ① Choose Windows layout by pressing win. ② Choose Mac OS layout by pressing mac.	
ctrl	Ctrl	Control ^
ept √ opt √	Start 📲	Option ~
ot cmd ₩	Alt	Command 🕷
alt md %	Alt (Right)	Command %
etd opt √=	Ctrl (Right)	Option ~

www.a4tech.com

(Product Specifications

Model: FX60H

Switch: Scissor Switch

Actuation Point: 1.8 ± 0.3 mm

Keycaps: Chocolate Style

Character: Silk Printing + UV

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 ~ F12

Report Rate: 125 Hz

Backlit Adjustable: FN + ◀ / ▶

Cable Length: 150 cm

Port: USB

Includes: Keyboard, User Manual

System Platform: Windows / Mac

www.a4tech.com

Q & A

TSTYLER.

Illuminate Low Profile Scissor Switch Keyboard

Question Can the keyboard support Mac platforms?

Answer Support: Windows | Mac keyboard layout switching.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why does the function light not indicate in Mac OS System?

Illuminate Low Profile Scissor Switch Keyboard

Answer Because the Mac OS system does not have this function.

www.a4tech.com