


130\*70mm




FG45C Air  
FG45CS Air




## QUICK START GUIDE

## WHAT'S IN THE BOX



## KNOW YOUR PRODUCT



## [ Desk + Air ] DUAL FUNCTIONS



Just lift up the mouse in the air to turn it into a multimedia controller.




## SCREENSHOT CAPTURES

- One click the capture button.
- Select the screenshot type by pressing the left key.
- Long press the left key and move the mouse cursor to capture the screen area.
- Release the left key and the screenshot will be recorded.
- You can paste the screenshot to another application.

\*\*\* Only supports Windows 10/11 or later.




## CONNECTING 2.4G DEVICE




- Plug the receiver into the computer's USB port.
- Use the Type-C adaptor to connect the receiver with the computer's Type-C port.

- Turn the mouse power switch to on.

## CHARGING & INDICATOR



## LOW BATTERY INDICATOR



## TECH SPEC

Connection: 2.4G Hz	Buttons No.: 7
Sensor: Optical	Charging Cable: 60 cm
Operation Range: 10~15 m	Size: 108 x 70 x 42 mm
Style: Right-Handed Fit	Weight: 80 g (w/ battery)
Report Rate: 125 Hz	System: Windows 7/8/8.1/10/11
Resolution: 1000-1200-1600-2000 DPI	

## Q & A

**Question** Do I need to install software for the [Desk+Air] mouse function?

**Answer** Just simply lift the mouse in the air then enjoy the mouse with multimedia control functions. No software installation required.

**Question** Is the air function fully compatible with all multimedia platforms?

**Answer** The mouse air function is created according to the Microsoft operation instructions. Except for the volume control function, the other multimedia functions might be limited use by some system platforms or third-party software support.

## WARNING STATEMENT

The following actions may/will cause damages to the product.

- To disassemble, bump, crush, or throwing into fire, you may cause irrefutable damages in event of the lithium battery leakage.
- Do not expose under the strong sunlight.
- Please obey all local laws when discarding the batteries, if possible please recycle it. Do not dispose it as household garbage, it may cause a fire or an explosion.
- Please try to avoid charging in the environment below 0°C.
- Do not remove or replace the battery.
- Forbidden to use 6V to 24V charger, otherwise the product will be burned. Recommended to use a 5V charger for charging.



www.a4tech.com



Scan for E-Manual